




## EXPLANATION

 Walker River Access Points

**Sensitive Species-**Represents the area in which the true location of observed extents of sensitive species are considered to occur. The type of sensitive species are located in or near the buffer points. For spills that occur near or in sensitive species areas during business hours call (775) 684-2900. After hours call (775) 882-2790 or (775) 782-4360

 100 meter buffer around observed location


 1600 meter buffer around observed location

 10,000 meter buffer around observed locations

 USGS Realtime Site


 Cities-Towns

 County Seat


 Ditch or Intermittent

 Perennial

 Railroads

 Railroad Spurs

 State Maintained Roads

 Basin Boundary


 State Park Boundaries


 County Boundaries

## Waterbodies

 Dry Lake

 Intermittent Waterbody

 Perennial Waterbody



Sources:  
Nevada Division of Environmental Protection  
Nevada Department of Transportation  
Nevada Natural Heritage Program  
U.S. Geological Survey  
NOTE: This map is for reference only. It has not been verified for deterministic purposes